
Commercial Frontload Washers SWF 1

Refer to Page 3 for Model Numbers






Parts Ordering Information

If literature or replacement parts are required, contact the source from whom the machine was purchased or contact Alliance Laundry Systems at for the name and address of the nearest authorized parts distributor.

For technical assistance, call either of the numbers listed below:

Nameplate Location

When calling or writing about your product, be sure to mention model and serial numbers. Model and serial numbers are located on nameplate(s) as shown.



H129P_800167


Model Identification

Information in this manual is applicable to these washer models:

HWF561*E1102	HWFX61*H1102	SWF661*E	SWFB61*H	SWFH61*J
HWF561*H1102	HWFY61*H1102	SWF661*H	SWFB61*J	SWFJ61*J
HWF761*E1102	HWFZ61*H	SWF761*E	SWFC61*H	SWFT61*H
HWFB61*J1102	HWFZ61*H1102	SWF761*H	SWFC61*J	SWFX61*H
HWFF61*J1102	SWF561*E	SWFA61*H	SWFD61*H	SWFY61*H
HWFT61*H	SWF561*H	SWFA61*J	SWFF61*J	SWFZ61*H
HWFT61*H1102				


^{*} Add Letter To Designate Color. L - Almond Q - Bisque W - White

Control Panel and Controls




FLW1689P_800167

Cabinet Top



Control Shield and Motor Control


Models HWF561*E1102, HWF761*E1102, SWF561*E, SWF661*E and SWF761*E



FLW971P_800167

Control Shield and Other Controls


All Models Except HWF561*E1102, HWF761*E1102, SWF561*E, SWF661*E and SWF761*E



FLW972P_800167

Wrapper Assembly and Coin Drop


Models HWF561*E1102, HWF561*H1102, HWFB61*J1102, HWFT61*H, HWFT61*H1102, HWFX61*H1102, HWFZ61*H, HWFZ61*H1102, SWF561*E, SWF561*H, SWFA61*H, SWFA61*J, SWFH61*J, SWFH61*J, SWFT61*H, SWFX61*H and SWFZ61*H



FLW973P_800167


Electronic Coin Drop

Models HWFB61*J1102, HWFT61*H, HWFT61*H1102, HWFX61*H1102, HWFZ61*H, HWFZ61*H1102, SWFA61*H, SWFA61*J, SWFB61*H, SWFB61*J, SWFT61*H, SWFX61*H and SWFZ61*H




FLW1005P_800167


Wrapper Assembly Models SWFC61*H and SWFC61*J



Wrapper Assembly and Card Reader Kit Models HWF761*E1102, SWF661*E, SWF661*H, SWF761*E, SWF761*H and SWFD61*H




Wrapper Assembly and Card Reader Models HWFF61*J1102, HWFY61*H1102, SWFF61*J, SWFJ61*J and SWFY61*H




FLW898P_800167

Front Panel, Older Style Door Assembly and Door Seal Models HWF561*E1102, HWF761*E1102, SWF561*E, SWF661*E and SWF761*E




H049PZ3A_800167

Front Panel, Newer Style Door Assembly and Door Seal




Dispenser Assembly




FLW820P_800167

Mixing Valve and Fill Hose




FLW881P_800167

Outer Tub, Front and Clamp Ring




Inner Basket, Trunnion, Bearing Housing and Pulley




FLW865P_800167

Motor and Belt




FLW937P_800167

Hoses and Pump




FLW974P_800167

Base, Panels and Rear Panel




FLW1027P_800167

Shipping Materials




H087P_800167

Wire Ties, Harness Clips and Lead-In Cord





H130P_800167

Special Tools




Labels (Drawing 1 of 2)
Models HWF561*E1102, HWF761*E1102, SWF561*E, SWF661*E and SWF761*E





H068P_800167

Labels (Drawing 2 of 2)
All Models Except HWF561*E1102, HWF761*E1102, SWF561*E, SWF661*E and SWF761*E



H132P_800167

Wire Harnesses and Wires

